

Quick Start Guide

Front Panel View:



Left knob : Loudness Compensation

- Turn the knob to switch between Loudness Compensation

Right Knob : Power and Input Selector and Volumes

- Briefly press for 3 sec to On/Off standby mode
- Brief press to Input Selector
- Turn the knob to adjust volume

Left Toggle Switch : Output Gain

- Upwards : High Gain
- Downwards : Low Gain

Right Toggle Switch : Output Phase

- Upwards : Phase Invert
- Downwards : Phase Normal

Display:

- VOL : 00 ~ 99
- Inputs : 1 : XLR input 2 : RCA input 3 : RCA input 4 : RCA input