


# NEO STREAM


## Quick Start Guide





### 1 Power




### 2 Input



Scan QR code for Set-Up Guide videos




### 3 Output



Before using NEO Stream, review the NEO Stream User Manual at <https://ifi-audio.com/product-guides/>


## Wi-Fi Set-Up

- 1 Connect Wi-Fi antenna and power supply DAC, Amplifier or Active Speakers via S/PDIF, RCA or USB




\*A power supply unit must be able to deliver minimum rated repetitive current.

- 2 Power on




- 3 Select Hotspot and set to ON




- 4 In your device's Wi-Fi setting, connect to 'iFi-Streamer'



- 5 On your phone browser enter "192.168.211.1" in to URL box (not search box)



- 6 Connect the iFi-Streamer to your local Wi-Fi network



Enter network password and press Connect



IP address will show once connected

- 7 Network status LED




- Connection speed
- Fast (Internet)
  - Slow (Internet)
  - Fast (Local network)
  - Slow (Local network)
  - No connection

- 8 Connect your phone back to local Wi-Fi network (If not already connected)

- 9 Go to Music Streaming section

## Ethernet Set-Up

- 1 Connect LAN and power supply DAC, Amplifier or Active Speakers via S/PDIF, RCA or USB




\*A power supply unit must be able to deliver minimum rated repetitive current.

- 2 Power on



- 3 Ready to connect



- Connection speed
- Fast (Internet)
  - Slow (Internet)
  - Fast (Local network)
  - Slow (Local network)
  - No connection



- 4 IP address will show once connected



## Music Streaming

**TIDAL**

Open Tidal app



Other compatible apps are available